




Dimensions



LED INDICATORS

GREEN & RED LIGHT	MEANING
GREEN LIGHT ON ONLY	POWER SOURCE IS CORRECTLY WIRED AND SAFE TO USE.
RED LIGHT ON ONLY	L1/GROUND ARE REVERSED.
GREEN & RED LIGHT ON	GENERATOR POWER NEEDS BONDING PLUG. PEDESTAL POWER IS HOT/NEUTRAL ARE REVERSED OR L2/GND REVERSED

50 Amp Input Plug Indicators



Performance

The ActiveStart is a unique device that is installed in series with the loads. This is quite different from a standard softstart that is wired directly to a motor and only has one function which is to start the motor.

The ActiveStart responds to an inductive load which generates a large spike in current and quickly current limits the device while initiating a softstart of the load. This is done without disturbing other appliances that are currently running on the same power source.

The Graphs below showcase this functionality:

